



PSR Dual Sport Kickstand Installation Instructions 08-04504 / DK5

*** Stock Chain Slider Modification Is Required ***

****Removable Thread Locking Compound is recommended on all bolt threads****

1. Verify bike model & kickstand application before installation!
2. Place bike securely on a center stand recommended.
3. Remove lower chain slider and bolt from the suspension linkage pivot.
4. Use a 1/2" drill bit to drill and enlarge the hole in the chain slider. **TAKE NECESSARY SAFETY CAUTIONS!** The metal bushing will be pushed out from the chain slider, it is normal.
5. Insert lower mounting spacer into the chain slider.
6. Remove left subframe to mainframe bolt.
7. Install PSR kickstand using the supplied M8x30mm flat head bolt at the subframe to mainframe bolt location. Do not tighten yet.
8. Install the chain slider with the lower mounting adapter behind the lower kickstand mounting hole and insert the supplied M8x80mm flat head bolt.
9. Tighten all bolts to factory spec.
10. Rotate kickstand through its entire travel and check for clearance prior to use.

Usage & Maintenance of PSR Dual Sport Kickstand:

1. Check all hardwares for tightness before each ride.
2. Do Not Start the bike with kickstand down.
3. Do Not Kickstart the bike with kickstand down.
4. Clean and lubricate the kickstand pivot area after each ride.