



## PSR YAMAHA WR250R/X LUGGAGE RACK INSTRUCTIONS:

1. Remove rear fender and flip it over
2. Note the four markings on the rear fender, use bit between 1/8" – 3/32" to drill pilot holes, then chase holes with 1/2" or 13mm drill bit.
3. Remove the four bolts holding the oem tail light/lower fender assembly with a 10mm socket(these four bolts will not be re-used). There will be two more bolt still holding it in place farther to the rear, do not remove them.
4. Reinstall the fender and push/force the included 1/2" spacers in place.
5. Bolt it all together with the four 70mm long flat head screws.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. PSR is not responsible for any losses, damages or claims resulting from injuries sustained or alleges to have been sustained by the installation of this product not installed by a certified mechanic experienced in the installation of component parts on motorcycles. PSR is not responsible for the functionality of the product not properly installed or under circumstances in which there has been a modification to the product by any person not employed by PSR.