



CBR1000RR 06-07 No Cut Frame Sliders
03-00907-02/03-00907-41

Frame Slider Instructions

Right Side:

1. Remove bodywork to expose mounting location
2. Remove right side engine stud.
3. Install the left side bracket using M12 x 1.25 x 90. Adjust the bracket so when the slider is mounted it will clear the bodywork.
4. When the bracket is in the correct position torque down to OEM torque specs.
5. Use blue loc tie to install the right slider on the bracket with M10 x 1.5 x45.
Torque down to 30 to 32 foot lbs.

Left Side:

1. Remove bodywork to expose mounting location
2. Remove left side engine stud.
3. Install the left side bracket using M12 x 1.25 x 80. Adjust the bracket so when the slider is mounted it will clear the bodywork.
4. When the bracket is in the correct position torque down to OEM torque specs.
5. Use blue loc tie to install the right slider on the bracket with M10 x 1.5 x 45.
Torque down to 30 to 32 foot lbs.

Install left and right bodywork using the spacers provided. Spacers is install between bodywork and bracket.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.