



### **Ducati Frame Slider Instructions**

1. Remove the Engine Mount Bolt
2. Remove Nut, Slider Puck, 2" Spacer, Split Washer and Metal Washer from one side.
3. Remove Rubber Grommet from middle.
4. Push Rod through one side of the top engine mount, leaving one side of all the hardware intact.
5. Be sure to space evenly so that both sides have enough rod spacing so that the case will be protected.
6. Slide on metal washer, split washer and the 2" spacer. Tighten slider puck and metal nut back onto rod.
7. Apply Thread locking compound to each side.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.