



## Fully Adjustable Lowering Link Installation Instructions

### Double Link style

1. Remove OEM links.
2. Install PSR adjustable links with the flat side of the ends facing inward. (EX250 08-12 and Ninja 300 may need the included longer bolts)
3. Tighten lowering link mounting bolts and nuts.
4. Inspect bike height; adjust as desired (Not to exceed the maximum center to center link length of 3 1/2")
5. Adjust each link equally and in the same direction.
6. Apply loctite and tighten link lock nuts.

**Cleaning/Maintenance:** It is recommended to remove and inspect the lowering linkage annually for possible bearing damage, cleaning, and/or re-greasing to keep it working at peak performance.

Always check all hardware and retighten if needed.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. PSR is not responsible for any losses, damages or claims resulting from injuries sustained or alleges to have been sustained by the installation of this product not installed by a certified mechanic experienced in the installation of component parts on motorcycles. PSR is not responsible for the functionality of the product not properly installed or under circumstances in which there has been a modification to the product by any person not employed by PSR.