



**GSXR600/750 11-15 No Cut Frame Sliders
05-00922-02/05-00922-41**

Frame Slider Instructions

Right Side:

1. Remove bodywork to expose mounting location
2. Remove right side engine stud.



3. Install the bracket using M10 x60 x 1.25 bolt and torque to factory spec.



4. Install the short slider with M10 x 50 bolt
5. Install fairing
6. Reinstall the fairings.



GSXR600/750 11-15 No Cut Frame Sliders
05-00922-02/05-00922-41

Left Side:

1. Remove bodywork to expose mounting location.
2. Remove the engine stud and factory spacer.



3. Install the Bracket with M10 x60 x 1.25 bolt and torque to factory spec.



4. Install the longer slider with M10 x50 bolt.
5. Reinstall the fairing.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.