



Frame Slider Instructions

Ninja 650 2009-2011

04-00921-02 04-00921-41

- 1) Remove the right faring
- 2) Remove 8mm bolt in line with the bracket for the faring, above the 10mm motor bolt.
- 3) Used the 8mm x 80mm bolt with the short spacer supplied.
- 4) Slide the bolt through the bracket with the “R” facing the inside along with the short spacer, and just start the bolt. Make sure to use blue loc-tie.
- 5) When tighten the bolt make sure the angle on the bracket matches up with the frame tube. When bolt is tight the bracket should be against the frame tube.
- 6) Put the right faring back on.
- 7) Mount the short slider on the bracket.
- 8) Remove the left faring.
- 9) Remove the 8mm and 6mm bolt from the bike.
- 10) If you hold the bracket up toe where the 6mm bolt goes into the center of the bracket, you will see how the bolts line up.
- 11) Use the long spacer and the 8mm x80mm supplied.
- 12) Hand tight the 8mm x80mm bolt with blue loc-tie.
- 13) Install the 6mm x19mm bolt through the bracket.
- 14) Tighten the bolts.
- 15) Put the Left faring back on.
- 16) Mount the long slider on the bracket.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.