



**R6 06-07 No Cut Frame Sliders
07-00904-02/07-00904-41**

Frame Slider Instructions

Right Side:

1. Remove bodywork to expose mounting location
2. Remove engine bolt.
3. Mount the right side slider, (short slider) with M10 x 90 x 1.25. There is a notch on the frame slider. The notch is to clear the body.
4. Torque down to OEM specs.
5. Reinstall the right side body panel, line up the notch with the body panel to clear with the slider.

Left Side:

1. Remove bodywork to expose mounting location
2. Remove left side engine stud.
3. Install the left side bracket using M10x70x1.25.
4. Make sure the bracket is the correct angle for the slider to clear the body.
5. Torque down to OEM torque specs.
6. Install the left side slider, (long slider) to the bracket using M10x45x1.5 bolt. Use one drop of blue thread locker and torque down to 30 to 32 foot lbs.
7. Reinstall the left side body panel.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.