



ZX10R 04-05 No Cut 04-00905-02/04-00905-41

Frame Slider Instructions

Right side:

1. Remove the bodywork to expose mounting location.
2. Remove right side 10mm engine bolt located below the foam flashing.
3. Install the flat offset with M10x1.25x80 bolt. Do not tighten up the bolt.
4. Move the bracket so the slider puck will clear the body. When you are sure the bracket location will clear the body then torque the engine bolt to OEM torque specs.
5. Install the bodywork.
6. Torque the slider to the bracket at 30 to 32ft lbs with blue loctite

Left side:

1. Remove the bodywork to expose mounting location.
2. Remove left side 10mm engine bolt located below the foam flashing.
3. Install the bracket with M10x1.25x70 bolt. Do not tighten up the bolt.
4. Move the bracket so the slider puck will clear the body. When you are sure the bracket location will clear the body then torque the engine bolt to OEM torque specs.
5. Install the bodywork.
6. Torque the slider to the bracket at 30 to 32ft lbs with blue locitie.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.