



Frame Slider Instructions
Kawasaki ZX14R 06-15
04-0098-02/04-00908-41

1. Remove the right side bolt.
2. Mount right side puck (short puck) with M10 X 110 X 1.25 Engine Stud and torque down.



3. Remove left side bolt.
4. Mount left side puck (long puck) with M10 X 110 X 1.25 Engine Stud and torque down.



Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.