



Lowering Link Installation Instructions

Dogbone Link style

1. Secure motorcycle to bike lift and raise the motorcycle so the rear wheel is un-weighted.
2. Loosen and remove the oem link.
3. Replace oem link with PSR's lowering links. (if OEM link has "center sleeve". Remove the center sleeve from oem link and install it into the PSR's lowering link.
4. Reinstall bolts, washers and nuts.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. PSR is not responsible for any losses, damages or claims resulting from injuries sustained or alleges to have been sustained by the installation of this product not installed by a certified mechanic experienced in the installation of component parts on motorcycles. PSR is not responsible for the functionality of the product not properly installed or under circumstances in which there has been a modification to the product by any person not employed by PSR.