



PSR Dual Sport Kickstand Installation Instructions 08-04500 / DK1

****Removable Thread Locking Compound is recommended on all bolt threads****

1. Verify bike model & kickstand application before installation!
2. Place bike securely on a center stand recommended.
3. Remove stock kickstand and kickstand brackets if applicable
4. Remove lower chain roller bolt. Be sure to note all parts removed for re-assembly.
5. Remove left subframe to mainframe bolt.
6. Install PSR kickstand using the supplied M8x30mm flat head bolt at the subframe to mainframe bolt location.
7. Line up and install the supplied lower mounting spacer and bolt M8x70mm socket head, into the lower mounting bracket. Install the chain roller. Be sure there is proper clearance on the length of the bolt.
8. Tighten all bolts to factory spec.
9. Rotate kickstand through its entire travel and check for clearance prior to use.

Usage & Maintenance of PSR Dual Sport Kickstand:

1. Check all hardware for tightness before each ride.
2. Do Not Start the bike with kickstand down.
3. Do Not Kickstart the bike with kickstand down.
4. Clean and lubricate the kickstand pivot area after each ride.