



## **BMW S1000RR 12-14 NO CUT 09-00904-02/09000904-41**

### **Frame Slider Instructions**

#### **Right Side:**

1. Remove the right lower and mid body panels to expose mounting location.



2. Remove the engine stud.



3. Leave conical spacers in the frame. Use M10 x60mm x 1.5 pitch bolt to install the bracket to the motorcycle.



4. The aluminum spacer is bolted to the back of the bracket.



5. Torque down the engine bolt to factory specification.
6. Reinstall the fairings.
7. Install the short slider on the bracket with M10 x50mm x 1.5 pitch bolt.

**Left Side:**

1. Remove engine stud.



2. Leave conical spacers in the frame. Install long slider on the motorcycle with M10 x90mm x 1.5 pitch bolt.
3. Torque the engine bolt to factory specifications.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.