



PSR Dual Sport Kickstand Installation Instructions 07-04502 / DK3

****Removable Thread Locking Compound is recommended on all bolt threads****

1. Verify bike model & kickstand application before installation!
2. Place bike securely on a center stand recommended.
3. Remove lower chain roller bolt. Be sure to note all parts removed for re-assembly.
4. Remove left subframe to mainframe bolt.
5. Install PSR kickstand using the supplied M8x30mm flat head bolt.
6. Reinstall the chain roller using supplied M8x70mm socket head bolt. Be sure there is proper clearance on the length of the bolt. (if the bolt is too long, cut off excess with a hacksaw or die grinder)
7. Tighten all bolts to factory spec.
8. Rotate kickstand through its entire travel and check for clearance prior to use.

Usage & Maintenance of PSR Dual Sport Kickstand:

1. Check all hardwares for tightness before each ride.
2. Do Not Start the bike with kickstand down.
3. Do Not Kickstart the bike with kickstand down.
4. Clean and lubricate the kickstand pivot area after each ride.