



## **PSR Frame Slider Instructions 2011-2012 CBR250R**

### **Left Side:**

1. Remove fairing fasteners to gain access to factory engine mount bolt & remove bolt
2. Install bracket and M10x80 bolt. Torque to factory spec.



3. Attach slider with M10x50 bolt.
4. Install fairing fasteners





**Right Side:**

1. Remove factory engine mount bolt
2. Install bracket & use M10x80 bolt & torque to factory spec.
3. Install slider with M10x50 bolt
4. Install fairing fasteners



Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.