



Frame Slider Instructions
Ninja EX650 06-08 No Cut Frame Sliders
04-00914-02/04-00914-41

Left Side:

1. Remove bodywork to expose mounting locations.
2. Remove lower 8mm motor bolt by radiator.
3. Install the larger bracket with the M8 x 1.25 x 45mm
4. Install the bodywork.
5. Used blue loc tie to install the slider on the bracket with M10 x 1.5 x 50mm

Right Side:

1. Remove bodywork to expose mounting locations.
2. Remove lower 10mm motor bolt.
3. Install the small bracket with the M10 x 1.25 x 150mm
4. Install the bodywork.
5. Used blue loc tie to install the slider on the bracket with M10 x 1.5 x 50mm

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun.