



Frame Slider Instructions CBR1000rr 17-19 No Cut 03-00923-02/03-00923-41

1. Remove both left and right side fairings to expose engine mounting bolts.
2. Remove right engine mounting bolt and the spacer behind the frame.
3. Install the right side bracket (curved shaped bracket) in place of the spacer removed from step #2.
4. Reinstall engine mounting bolt and tighten to factory spec.
5. Refer to the picture for the bracket mounting location on the left side of the frame.
6. Feel the opening in the back side of the frame with your finger. Install the left bracket by placing the round mount inside the frame opening as pictured.
7. Install the oval bracket with 2 included screws to securely attach the bracket assembly to the frame.
8. Reinstall the fairing removed in step #1, the frame slider mounting holes on the brackets should be visible thru the fairing openings.
9. Install the longer slider to the right side bracket, and the shorter one to the left side.



Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. PSR frame sliders are meant to help possibly minimize the damages in the event of a crash. PSR do not guarantee the frame sliders will protect your motorcycle from any extent of damage when the bike is dropped or crashed. Customers shall not assume no damages will happen when the frame sliders are installed. PSR is not responsible for any part of your motorcycle for any reason. Precisely measure location of cut and if in doubt at any point please call us before the install process has begun