



Lowering Link Installation Instructions
Suzuki DRZ400
05-04201-29/05-04202-29 MX Lowering Link

1. Place the bike on a box stand.
2. Remove the two 17mm nuts that hold the links to the rocker and the swing arm and push the bolts out the left side.
3. Push the four bushings out of the stock links with a 16-18mm punch, and reinstall them in the PSR link with the washer part on the inside.
4. Be sure the thick stock washer on both sides of the rocker and swing arm mounts are over the bearing sleeve, and are pressing against the seal before the link mounting bolts are tightened.
5. Torque both link mounting bolt nuts to 72.5 lb-ft.

For the best performance set the sag at 2.75" for 05-04202-29 link, or 3.25" for 05-04201-29.

If the links are for lowering purposes only, set the sag at 3.75"

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. PSR is not responsible for any losses, damages or claims resulting from injuries sustained or alleges to have been sustained by the installation of this product not installed by a certified mechanic experienced in the installation of component parts on motorcycles. PSR is not responsible for the functionality of the product not properly installed or under circumstances in which there has been a modification to the product by any person not employed by PSR.