



Black Mick: Fork Lift Stand

While we manufacture our products to a very high standard, we can't guarantee any stand that isn't assembled correctly or used incorrectly. Please be sure that you understand the instructions and if not contact PSR for advice before use. PSR will not be held responsible in the instance of an incorrectly assembled stand. When using this service stand be sure the motorcycle and exhaust system are completely cool and the motorcycle is on a level and hard surface! **ALWAYS USE A REAR STAND SECURELY WHILE USING THE FRONT STAND!**

1. Assemble uprights to the base. (Use quick release pins for versatility, or use nut & bolt hardware to eliminate free play)
2. Referring to Picture A below, insert Left & Right fork lift hardware respectively.

Make sure the stand is centered against the front wheel, check width of Fork Lift hardware according to the motorcycle's inner width between the forks. The Fork Lift arm should rotate freely, if not, lubricate with WD-40 if necessary.



Picture A



Check out other great products by PSR: Adjustable Rearsets, CNC engine case covers, engine case armors, racing chain adjusters, digital tire warmers, Click 'N Roll race levers, remote brake adjusters, Powerchock, PowerPlatform, Kingpin - Wheel Tree, PowerJack stands & More!

Warranty: PSR products are intended for closed course competition purposes only, and therefore are sold "as is" WITHOUT warranty. PSR specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts. Rubberized parts wearing out & scrapes on the bottom of the stand are part of normal wear and tear.