




PowerChock: Self Locking Wheel Chock

While we manufacture our products to a very high standard, we can't guarantee any stand that isn't assembled correctly or used incorrectly. Please be sure that you understand the instructions and if not contact PowerStands Racing for advice before use. PowerStands Racing will not be held responsible in the instance of an incorrectly assembled stand. When using this service stand be sure the motorcycle and exhaust system are completely cool and the motorcycle is on a level and hard surface!

Standalone Assembly & Usage:

1. Assemble front stop with supplied hardware securely tighten. (picture A)
2. Assemble pivot arm according to front wheel size. (Front hole: 16-17 inch wheels, middle hole 17-18 inch wheels, Rear hole 18-19 inch wheels)
3. Place PowerChock on level surface, make sure the pivot arm is tilted away from the front stop
4. Slowly roll the bike's front tire onto and over the pivot arm and into the PowerChock
5. Be sure the front tire situated in the PowerChock is as vertically straight as possible
6. Additional security is achieved with tie downs.



Using PowerChock with PowerPlatform – Portable Folding Work/Display Table (sold separately):

*additional supplied hardware is to be used in conjunction with PowerPlatform – Portable Folding Work / Display Table.(picture B)

1. Remove front stopper from the PowerPlatform replace it with PowerChock.
2. Align the holes on the PowerChock and the holes on the table surface, insert locking pin into each hole to secure PowerChock in place
3. Slowly roll the bike's front tire onto and over the pivot arm and into the PowerChock
4. Be sure the front tire situated in the PowerChock is as vertically straight as possible
5. SECURE BIKE WITH TIE DOWN. Rear stand is recommended to achieve additional security.

Check out other great products by PowerStands Racing: Adjustable Rearsets, CNC engine case covers, engine case armors, racing chain adjusters, digital tire warmers, Click 'N Roll race levers, remote brake adjusters, Powerchock, PowerPlatform, Kingpin - Wheel Tree, PowerJack stands & More!

Warranty: PowerStands Racing products are intended for closed course competition purposes only, and therefore are sold "as is" WITHOUT warranty. PowerStands Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts. Rubberized parts wearing out & scrapes on the bottom of the stand are part of normal wear and tear.